

**Table DT-2
Absorption Field**

After determining the site percolation rate, the following table shall be used to determine the required absorption field area.

Percolation Rate (Minutes/Inch)	Absorption field area per Bedroom (Square Feet)
5	125
10	165
15	190
20	210
25	230
30	250
35	265
40	280
45	300
50	310
55	325
60	335
65	345
70	355
75	365
80	370
85	375
90	380
95	385
100	390
105	395
110	400
115	405
120	410

For sites less than 3 acres in size, soil horizons that exceed a percolation rate of 90 minutes per inch shall not be considered for installation of a conventional on-site sewage management system.

For sites of 3 acres or more in size, soil horizons that exceed a percolation rate of 120 minutes per inch shall not be considered for installation of a conventional on-site sewage management system.